


## DSL Setup Guide for Dlink G604T

1. Open your web browser (e.g. Internet Explorer, Mozilla Firefox, Google Chrome, etc)
2. Enter the following into the address bar: **192.168.1.1**
3. You will be prompted to enter a username and password
  - **Username:** admin
  - **Password:** admin
4. Click on **Login**
5. Click on **Run Wizard**



6. Click on **Next**
7. Select your **Time Zone**
8. Then click **Next**
9. Select **PPPoE/PPPoA**
10. Click **Next**
11. For **Username** - enter your MyNetFone DSL Username (*make sure to use the correct username format e.g. [username@dsl.mynetfone.com.au](mailto:username@dsl.mynetfone.com.au)*)
12. For **Password** - enter your MyNetFone DSL Password
13. For **VPI** - enter 8
14. For **VCI** - enter 35
15. For **Connection Type** - select **PPPoE LLC**



16. Click **Next**
17. Click **Restart** to save the settings and reboot the modem.