

Wireless Setup Guide for Dlink G604T

1. Ensure your computer is connected to your Billion modem with an Ethernet cable
2. Open your web browser (e.g. Internet Explorer, Mozilla Firefox, Google Chrome, etc)
3. Enter the following into the address bar: **192.168.1.1**
4. You will be prompted to enter a username and password
 - **Username:** admin
 - **Password:** admin
5. Click on **Login**
6. On the left side menu, click on **Wireless**
7. Check the box for **Enable AP**
8. Change the **SSID** to something that is unique. The SSID differentiates one WLAN from another.
9. For **Security** - select **WPA**
10. Then select **PSK String**
11. Type a unique password PSK String

The password required to login to your wireless connection. When a computer or laptop tries to connect to your Network they will be prompted to enter this password.

- Must have a minimum of 8 alphanumeric characters
- This key is case sensitive

The screenshot shows the 'Wireless Settings' page in a web browser. The left sidebar contains navigation buttons: Wizard, Wireless (highlighted), WAN, LAN, DHCP, DNS, DynamicDNS, and Logout. The main content area has tabs for Home, Advanced, Tools, Status, and Help. Under 'Wireless Settings', there is a sub-header and a description: 'These are the wireless settings for the AP(Access Point) Portion.' Below this, several settings are visible: 'Enable AP' (checked), 'SSID: My home wireless', 'Channel: 6', 'Security: WPA', 'Group Key Interval: 3600', and a note about the Group Key Interval. There are three radio button options for security: '802.1x', 'PSK Hex', and 'PSK String' (selected). The 'PSK String' field contains 'Pa55W0rD'. At the bottom, there are three buttons: 'Apply' (with a green checkmark), 'Cancel' (with a red X), and 'Help' (with a red plus sign).

12. Click on **Tools** in the top menu
13. Then click on **System** on the left menu
14. Now click on **Save and Reboot**