

DSL Setup Guide for Netcomm NB6Plus4N

1. Open your web browser (e.g. Internet Explorer, Mozilla Firefox, Google Chrome, etc)
2. Enter the following into the address bar: **192.168.1.1**
3. You will be prompted to enter a username and password
 - **Username:** admin
 - **Password:** admin
4. Click on **Login**
5. On the top left hand side, click on **Quick start**
6. On the menu on the left side, click on **Quick Setup**
7. For **VPI** - enter 8
8. For **VCI** - enter 35
9. Click **Next**
10. For **Protocol** field - select **PPP over Ethernet (PPPoE)**
11. Click **Next**
12. Select **Obtain an IP address automatically**
13. Check the box **Enable NAT**
14. For **MTU** - enter 1492
15. Click on **Next**
16. For **Username** - enter your MyNetFone DSL Username (*make sure to use the correct username format e.g. username@dsl.mynetfone.com.au*)
17. For **Password** - enter your MyNetFone DSL Password
18. Click **Next**
19. Then click **Finish**
20. Your modem should reboot now.