


VoIP Setup Guide for Netcomm NB9

1. Open your web browser (e.g. Internet Explorer, Mozilla Firefox, Google Chrome, etc)
2. Enter the following into the address bar: 192.168.1.1
3. You will be prompted to enter a username and password
 - **Username:** admin
 - **Password:** admin
4. Click on **Login**
5. On the top left side menu, click on **Voice**
6. Check the box for **Use SIP Proxy**
7. For **SIP Proxy** - enter your MyNetFone SIP Proxy
8. For **SIP Proxy Domain** - enter your MyNetFone SIP Proxy
9. For **Register Expire Time** - enter 120



Voice -- SIP configuration

Enter the SIP parameters.

Interface name:

Local selection:

Priority Codec/Ptime:
 1st: 2nd: 3rd:

Use SIP Proxy.

SIP Proxy:

SIP Proxy port:

SIP Proxy Domain:

Register Expire Time:

DispName:	VoIP Phone Number:	Auth. ID:	Auth. Password:
1. <input type="text" value="Mynetfone Number"/>	<input type="text" value="Mynetfone Number"/>	<input type="text" value="Mynetfone Number"/>	<input type="password" value="....."/>
2. <input type="text" value="Mynetfone Number"/>	<input type="text" value="Mynetfone Number"/>	<input type="text" value="Mynetfone Number"/>	<input type="password" value="....."/>

For Number 1, enter the following:

10. For **DispName** - enter your MyNetFone Number
11. For **VoIP Phone Number** - enter your MyNetFone Number
12. For **Auth. ID** - enter your MyNetFone Number
13. For **Auth. Password** - enter your MyNetFone Password

For Number 2, enter the following:

14. For **DispName** - enter your MyNetFone Number
15. For **VoIP Phone Number** - enter your MyNetFone Number
16. For **Auth. ID** - enter your MyNetFone Number
17. For **Auth. Password** - enter your MyNetFone Password

18. Scroll down the page and click on **Apply and Save All VoIP Parameters** to apply the settings