

## VoIP Setup Guide for Netcomm NB9WMAXXn

1. Open your web browser (e.g. Internet Explorer, Mozilla Firefox, Google Chrome, etc)
2. Enter the following into the address bar: **192.168.1.1**
3. You will be prompted to enter a username and password
  - **Username:** admin
  - **Password:** admin
4. Click on **Login**
5. On the top left side menu click on **Voice**
6. Select **SIP Basic Setting**
7. Check the box for **Use SIP Proxy**
8. For **SIP Proxy** - enter your Mynetfone SIP Proxy
9. For **Register Expire Time** - enter 120
10. For **SIP Proxy Domain** - enter your MyNetFone SIP Proxy
11. Check the box for **Use SIP Outbound Proxy**
12. For **SIP Outbound Proxy** - enter your MyNetFone SIP Proxy
13. For **SIP Outbound Proxy port** - enter 5060

**Voice > SIP configuration**

Enter the SIP parameters and click Start/Stop to save the parameters and start/stop the voice application.

Interface name:

Local selection:

Preferred codec list:

Preferredptime:

Use SIP Proxy.

SIP Proxy:

SIP Proxy port:

Registration Expire Timeout:

SIP domain name:

Use SIP Outbound Proxy.

SIP Outbound Proxy:

SIP Outbound Proxy port:

Line Enabled	Extension	Display Name	Authentication Name	Password
1 <input checked="" type="checkbox"/>	Mynetfone Number	Mynetfone Number	Mynetfone Number	••••••••
2 <input checked="" type="checkbox"/>	Mynetfone Number	Mynetfone Number	Mynetfone Number	••••••••

For Number 1, enter the following:

14. For **DispName** - enter your MyNetFone Number
15. For **VoIP Phone Number** - enter your MyNetFone Number
16. For **Auth. ID** - enter your MyNetFone Number
17. For **Auth. Password** - enter your MyNetFone Password

For Number 2, enter the following:

18. For **DispName** - enter your MyNetFone Number
  19. For **VoIP Phone Number** - enter your MyNetFone Number
  20. For **Auth. ID** - enter your MyNetFone Number
  21. For **Auth. Password** - enter your MyNetFone Password
22. Scroll down the page and click on **Save/Apply** to apply the settings