



MNF VPBX Quickstart Guide (without PoE Switch)

Connecting the Phone to the PoE Switch

Linksys Phone (SPA 922, 942, and 962)

1 - Find the end of the coiled phone cord that has the longer straightened end. Plug that end into the back of the phone base (phone symbol).

2 - Plug in short straightened end of the handset cord into the jack at the bottom of the handset (not shown).

3 - Push the power cord (PA100) into the power supply, and plug the power supply into the phone base unit. Use only the power supply that came with the phone.

3 - Plug the ethernet cable into the back of the base station. Plug the other end of the Ethernet cable into Internet.

4 - For SPA922, SPA942 and SPA962 a second ethernet port can be used to connect a PC.

5 - The AUX RJ-11 port is reserved for Receptionist Console Sidecar of the SPA962. It is not for use as a telephone line port.

DO NOT PLUG IN A TELEPHONE LINE CORD INTO THE AUX PORT.




Figure: Attaching the phone cords and network cables (steps 1 through 4)

Phone Boot-up

- The phone will execute a boot-up sequence when the Ethernet cable to PoE switch is connected.
- During this sequence, the display will first show **LINKSYS®** and then “Initializing Network”.
- All of the lights on the phone will flash.
- After the sequence, which should take about five seconds, the phone will display the standard menu for the phone.
- The date, name and number of the phone will display on the top line of the LCD screen.

At the bottom of the LCD screen redial, dir, cfwd and dnd are displayed over their associated soft buttons. A small arrow appears next to dnd indicating that more menus can be accessed by pushing the right side of the navigation button.

If the phone does not provide this screen, re-confirm installation and connections. If these are correct, try unplugging the phone and plugging it back in again. If you still don't see the display, then contact **MyNetFone Business Support – 1300 887 899**

Attaching the Desk Stand

- 1 - Line up the tabs on the desk stand with the slots on the back of the phone.
- 2 - Slide the bottom tabs into the slots
- 3 - Lightly press down on the top of the desk stand. It should easily slide into the top slots. Do not force.



Desk Stand Attached to Phone

2.1 SNOM Phone (SNOM 300, 320, and 360)

SNOM 300

Connect one end of the handset cable to the handset and the other end to the jack on the phone's bottom shell with the handset symbol. Clip the handset cord into the groove on the bottom shell of the phone, as shown in figure.




Figure: Attaching Handset Cables

Plug the Ethernet (network) cable into the RJ45 connector labeled "NET" and plug the other end into your Internet. The second RJ45 connector, labeled "PC", can be used to connect a PC. Insert the plug of the power supply into the connector labeled "DC 5V" and hook up the casing into the mains.




Figure: Attaching the Network Cables

SNOM 320/360

First connect one end of the handset cable to the handset and then to the jack on the right-hand side (handset symbol) of the phone's bottom. Next plug the Ethernet (network) cable into the RJ45 connector labeled "NET", and plug the other end into your Internet. The second RJ45 connector, labeled "PC", can be used to connect a PC. Insert the plug of the power supply into the connector labeled "DC 5V" and hook up the casing into the mains.




Figure: Attaching Network and Handset Cables

Phone Boot-up

- The phone will execute a boot-up sequence when the Ethernet cable to PoE switch is connected.

The phone tries to register your account name. The idle screen appears. Your registration has been successful if the identity is shown in the top line. If, however, the letters "NR" is shown instead, the registration has not been successful then contact **MyNetFone Business Support – 1300 887 899**.

Now your MNF VPBX is already setup and ready to make calls.

MNF Virtual PBX System

