

## VoIP Setup Guide for Billion 7401VGPM

1. Open your web browser (e.g. Internet Explorer, Mozilla Firefox, Google Chrome, etc)
2. Enter the following into the address bar: **192.168.1.254**
3. You will be prompted to enter a username and password
  - **Username:** admin
  - **Password:** admin
4. Click on **Login**
5. On the top left side menu, click on **Configuration**
6. Click on **VoIP**
7. Then click on **General Settings**
8. Navigate to **“Setting for Phone Port 1”**
9. For **Registrar Address(or Hostname)** - enter your MyNetFone SIP Proxy
10. For **Expire** - enter 120
11. For **User Domain/Realm** - enter your MyNetFone SIP Proxy
12. For **Outbound Proxy Address** - enter your MyNetFone SIP Proxy
13. Click on **Apply**

General Settings	
SIP Device Parameters <span style="float: right;">Advanced ▶</span>	
SIP	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
Silence Suppression (VAD)	<input type="radio"/> Enable <input checked="" type="radio"/> Disable
Echo Cancellation	<input checked="" type="radio"/> Enable <input type="radio"/> Disable
RTP Port	5100
Region	Australia ▼
Voice QoS, DSCP Marking	Premium ▼
Setting for Phone Port 1 <span style="float: right;">Sync Now</span>	
Registrar Address(or Hostname)	Mynetfone SIP Proxy
Registrar Port	5060
Expire	120 seconds
User Domain/Realm	Mynetfone SIP Proxy (If empty, it is the same as Registrar Address.)
Outbound Proxy Address	Mynetfone SIP Proxy (If empty, it is the same as Registrar Address.)
Outbound Proxy Port	5060
<p><b>⚠ Please note:</b> VoIP configuration changes will only take effect when you use apply changes and select <b>Sync Now</b> for the relevant line, or when you apply changes, save configuration and restart the device.</p> <p><input type="button" value="Apply"/> <input type="button" value="Cancel"/></p>	

14. On the left side menu, click on **Phone Port**
15. Click on **Edit** on the right side

Phone Configuration				
Phone Port				
Index	Phone Number	Display Name	Registered	
1			unknown	<input checked="" type="button" value="Edit ▶"/>
<p><b>⚠ Caution!</b> The VoIP configuration will take effect only when you apply the changes, save configuration and restart the device.</p>				

16. For **Phone Number** - enter your MyNetFone Number
17. For **Authentication Username** - enter your MyNetFone Number
18. For **Password** - enter your MyNetFone Password
19. Re-enter your MyNetFone Password to **Confirm Password**
20. For **Display Name** - enter your MyNetFone Number
21. Click on **Apply**

**Phone Port 1**

**Login Account Configuration**

Phone Number	Mynetfone Number
Authentication Username	Mynetfone Number
Authentication Password	••••••••
Confirm Password	••••••••
Display Name	Mynetfone Number

**Codec Preference**

Priority 1	G.729
Priority 2	PCMU (G.711 u-Law)
Priority 3	PCMA (G.711 A-Law)
Priority 4	Non-used
DTMF Method	RFC 2833

**Speed Dial**

2#	
3#	
4#	
5#	
6#	
7#	
8#	
9#	

[Volume Control](#)

22. Click on **Save Config** in the bottom right corner
23. You will be asked to confirm. Click on **Apply** to save your settings (note, it may take up to one minute to save your settings)
24. Click on **Logout** in the bottom right corner